



PARTS LIST OF MAXXSP5

ITEM#	DESCRIPTION	PART#(05)	ITEM#	DESCRIPTION	PART#(05)
1	Drag Knob Assembly	1529593	30	Bearing Retainer	1280406
2	Retainer Ring	1092606	31	Washer	1114764
3	Spool Washer	1280353	32	Bearing 7*14*4	1085280
4	Key Washer	1280355	33	Bearing Holder	1115558
5	Washer	1536759	34	Clutch Assembly	1102144
6	Spool	1529594	35	Pinion	1536762
7	Spool Assembly	1529595	36	Clutch Spring	1252716
8	Washer (T=0.5)	1178949	37	Handle Screw	1529964
9	Click Gear	1085271	38	Washer	1092781
10	Main Shaft	1280357	39	Body	1529965
11	Nut Set Screw	1529596	40	Slider Retainer	1121651
12	Rotor Nut	1085606	41	Screw	1385624
13	Bail Arm Screw	1448222	42	Slider	1188579
14	Bail Holder	1529597	43	Screw	1126275
15	Bushing	1188261	44	Rear Cover	1529966
16	Screw	1536760	45	Bushing	1108938
17	Bail Arm	1529598	46	Oscillation Gear	1280412
18	Brass Bushing	1536761	47	Reduction Gear	1256967
19	Line Roller	1529959	48	Bearing 7*11*3	1092725
20	Washer	1529960	49	Drive Gear	1280411
21	Bail Assembly	1529961	50	Washer	1085287
22	Screw	1411137	51	Body Cover	1529967
23	Bail Arm Cover	1529962	52	Screw	1529968
24	Trip Spring	1126273	53	Handle Rivet Assembly	1529969
25	Trip Linkage	1252713	54	Bushing	1529970
26	Bail Slider	1128143	55	Handle Knob	1529971
27	Trip Bar	1280403	56	Screw	1119121
28	Rotor	1529963	57	Handle Knob Cover	1529972
29	Screw	1197283	58	Handle Assembly	1529973