


MODEL: PFL SP PRESXTSP40

ITEM	DESCRIPTION	SAP #		ITEM	DESCRIPTION	SAP #
1	DRAG KNOB ASSY	1416066		34	ROTOR NUT	1200857
2	SCREW	1200745		35	BUSHING	1210765
3	SPOOL RING	1359849		36	CLUTCH WASHER	1205956
4	KEY WASHER	1201739		37	SCREW	1200799
5	DRAG WASHER	1225637		38	BEARING COVER	1200800
6	EARED WASHER	1205941		39	BEARING	1200862
7	SPOOL SUB-ASSY	1416140		40	BEARING SLEEVE	1201777
7A	COMPLETE SPOOL VENTED	1416141		41	WASHER	1205969
8	SPOOL CLICK	1216395		42	ONE WAY CLUTCH	1200803
9	SPOOL SPRING	1214415		43	CLUTCH SPRING	1200805
10	SCREW	1216396		44	PINION GEAR	1415993
11	SHEET WASHER	1201745		45	N-R LEVER SPRING	1200806
12	WASHER	1200833		46	N-R LEVER SHAFT	1200870
13	BEARING	1200773		47	SCREW	1205959
14	SLEEVE	1200835		48	N-R LEVER	1201789
15	CLICK GEAR	1201749		49	DUST CAP ASSY	1415994
16	MAIN SHAFT	1378508		50	BEARING	1303506
17	SCREW	1200784		51	DRIVE GEAR	1415995
18	BAIL HOLDER	1275907		52	GEAR WASHER	1200876
19	BAIL WIRE SUB-ASSY	1275869		53	BODY COVER ASSY	1415996
20	WASHER	1200780		54	SCREW	1200816
21	LINE ROLLER	1200782		55	SCREW	1210701
22	BEARING	1200781		56	HANDLE ASSY	1415997
23	LINE ROLLER COLLAR	1201757		57	SCREW	1200819
24	BAIL ARM	1275909		58	O/S SLIDER	1216583
25	SCREW	1205887		59	SCREW	1248988
26	SCREW	1200787		60	O/S GEAR BUSHING	1216641
27	ROTOR COVER	1275870		61	O/S GEAR ASSY	1241390
28	BAIL SPRING	1200850		62	BEARING	1415998
29	BAIL ARM GUIDE	1200851		63	SCREW	1205909
30	TRIP PLUNGER	1206629		64	O/S SLIDER PLATE	1205972
31	ROTOR SUB-ASSY	1416142		65	INNER COVER	1378503
32	SCREW	1200794		66	REAR COVER	1378504
33	ROTOR NUT RETAINER	1200795		67	BODY ASSY	1416143

EXPLODED VIEW



PFL SP PRESXTSP40 00